

This Kit, PN 11683, is for Bike Models 593. This Kit adapts tank 10497 to older model 593 which used tank PN PX2257 and includes the following:

Qty	P.N.	Description
1	10497	Tank
1	10697	Fitting 1/8 NPT ¼ hose
1	11683R2	Installation Instructions
4	PX2304	1/4 X .625 Self Tap Bolt
4	1844	1/4-20 X .50 Bolt
4	2449	Tinnerman Nut
1	5246	Fuel Cap
2	11661-2	Tank Adapter

Tools Required: A 7/16 inch wrench and a 3/8 inch wrench.

Steps for Installation: (Refer to FIGURE 1)

1. Drain the gasoline in the fuel tank before disconnecting fuel line from the old tank.
2. Remove the old tank from the bike frame.
3. Measure distance "X" (Ref. Figure 1)
4. If distance "X" is 5.50 inches, Install the tank by inserting the PX 2304 self tapping bolts up through the tank bracket and threading into the tank. The other hardware will not be used.
5. If distance "X" is 4.75 inches, install the tank as indicated in figure 1.